

Personal Audio System


Startup Guide / Guide de démarrage / Anleitung für die Inbetriebnahme / Guía de inicio rápido / Guida all'avvio / Snelstartgids / Guia de Inicio Rápido / Käynnistysopas / Uppstartguide / Instrukcja uruchamiania / Használatba vételi útmutató / Příručka spouštění / Příručka spustenia / Руководство по началу работы / Посібник із налаштування



<http://www.sony.net/>


©2012 Sony Corporation Printed in China

ZS-S10CP




1

**Bottom / Partie inférieure / Unterseite /
Parte inferior / Parte inferiore / Onderkant /
Parte inferior / Pohja/ Nedtill / Spód / Alul /
Spodní část / Spodná časť / Нижня часть /
Нижня частина**




2




RADIO


1



2




3




CD


1




2




3



4



5



6

